



### How To Add the Camera DVR Access to Mobile Devices:

- 1) Download the **Wirepath WPS-DVR Application** from the App Store
- 2) Once installed, launch the application
- 3) At the top left of the screen click **"Add"**. Fill out the information as shown below:  
**Device Name:** *(Pick a name, Home would work for your main house)*  
**Address:** IP address or DDNS address  
**Control Port:** *67 (Default)*  
**Data Port:** *68 (Default)*  
**User Name:** *(The Username that we setup for you)*  
**Password:** *(The Password that we setup for you)*  
**Number of Cameras:** *(As available from the DVR)*  
**Default View:** *(Select which view you want to see when you first open the DVR device)*  
**Video Stream:** *Record (Default)*  
**Auto Connect:** *On (Default)*
- 4) After all the information is entered, double check it and then press **"OK"** at the top. This will bring you back to the Device List page where you should now see the one you just added.
- 5) Select the Device by **pressing the name** and if all information is entered correctly it will load your Default View and will show the live footage. (This may take a few seconds depending on network speeds)

### Notes:

- If it doesn't load any of the cameras after 30 seconds to a minute some portion of the information that was entered may be incorrect. Go back to the Device List by selecting **"Devices"** at the top and **then press the arrow at the right side of the Name of your DVR Device**. This will bring up the fields where you entered all the information. Make sure that it is all correct, select **"OK"** and then try re-selecting your DVR Device from the list.
- If the Password is incorrect it will tell you when it tries to load up the cameras saying the password is incorrect. Go back into the information and re-enter the password and try again.